



1863 Eastman Ave.
Ventura, Ca. 93003
www.arp-bolts.com

Part Number: 206-1001

Application: BMW 1.6L (W10/W11) MINI 4-CYL

Cam Bolt Installation

- [1] Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- [2] Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
- [3] Lubricate the threads of the bolt, the under head of the bolt and the washer where it contacts the timing gear with **ARP Ultra-Torque Fastener Assembly Lubricant**.
- [4] Install the camshaft, the camshaft caps and the timing gear as described in the factory service manual (if removed). Then install the bolt onto the camshaft and tighten it hand tight.
- [5] While keeping the camshaft from rotating, torque the bolt to 80 ft lbs with **ARP Ultra-Torque Fastener Assembly Lubricant**.

If you have any questions or need additional information please contact us at **(805) 339-2200** or by FAX at **(805) 650-0742**